



SNOC

MAINTENANCE
INSTRUCTIONS FOR

TEAK WOOD

FOR ENQUIRIES PLEASE CONTACT
EKVATOR ISI MUHENDISLIK INŞ SAN. VE TIC. LTD. ŞTİ.
CVR: 330 019 1329
T: +90 850 800 6464 - MUSTERIHIZMETLERI@SNOC.COM.TR

SNOC-EU.COM

CHARACTERISTICS

Teak furniture highlights the beauty and texture of Teak wood. Due to the natural variations of the wood, there may be differences in texture and color between pieces. Natural Teak will gradually develop a beautiful silver-gray patina over time. The aging process will vary depending on external factors, climate, usage, and maintenance with Teak oil. To protect the furniture from external elements, we recommend using our specially designed protective covers. This will help extend the lifespan of the product and minimize the impact of weather conditions.

OIL SURFACE

Teak wood has a dense and high oil content, making it particularly suitable for outdoor use. The natural oils in Teak provide resistance against fungi, termites, and woodboring insects. The natural oils in teak may surface as a result of exposure to rain and humidity and appear like water stains. This is a normal occurrence and it is part of the wood's characteristics. When you encounter such a situation:

- Use the SNOC Teak Maintenance Kit to clean the product and remove any oiliness from surface.
- Applying the SNOC Teak Maintenance Kit will help make the wood more resistant to moisture and staining.
- After allowing it to dry, you can gently sand away any remaining stains using 120-grit sandpaper.

CARE & MAINTENANCE

- Applying the SNOC Teak Maintenance Kit before the initial use of the product and at the end of each season will help preserve the original quality of Teak wood, enhance surface resistance against moisture, UV rays, food and beverage stains, and pests.
- We recommend using Snoc Teak cleaner to remove stubborn stains. Spray water onto the furniture from a distance of approximately 30 cm, ensuring that it does not exceed a maximum of 83 bar (1200 psi). Rinse and allow it to dry in the sun.
- Over time, Teak wood may develop an increased presence of wood grain due to exposure to moisture. In such cases, gently sanding the surface with 120-grit fine sandpaper will smooth the surface.
- Before starting maintenance on your Teak products, it is essential to clean the surface using 220-grit sandpaper. Otherwise, the desired results may not be achieved from the oiling process without sanding.

RECOMMENDATIONS

- Avoid allowing water to accumulate on the surface of furniture and cushions. This can lead to staining and water penetration into the fabric's inner surface.
- We recommend using SNOC protective covers in appropriate sizes for your products.

- When using protective covers, ensure that the furniture and cushions are clean and dry.
- If possible, remove the cushions before covering the furniture with the protective cover.
- If the cushions get wet, position them with the zipper facing downwards and open to allow all the water to drain out.

The information included in these materials is guidance on the proper care and maintenance of SNOC products, but this guidance can not be considered a guarantee of specific results. SNOC is not liable for any damage resulting from care and maintenance activities. Information from suppliers of chemicals and cleaning solvents, including but not limited to label instructions, should always be followed.